

# UV Lighted Bollard Cover Installation Instructions

## What You Will Receive:

- Designated number of Bollard Covers
- Two pieces of neoprene tape for each Bollard Cover

## Installation Instructions:

### Step #1

- Remove the back of the first adhesive tape strip
- Wrap it firmly around the top of the post, approximately 6" from the top
- Make sure to leave a 1" gap between the ends of the tape to allow airflow while installing the cover



### Step #2

- Remove the back of the second adhesive tape strip
- Wrap it firmly around the bottom of the post, approximately 6" from the bottom
- Do not leave a 1" gap this time around, make sure ends of tape connect

### Step #3

- With the tape in place, slowly slide the Ideal Shield Bollard Cover over the post.
- If the tape is applied correctly, you will hear air being forced out while sliding it down the post, creating a vacuum seal.
- The Ideal Shield Bollard Cover is now secure over the pipe.



### Step #4

- Remove protective bubble wrap and protective tape over solar panel before use

**THANK YOU FOR YOUR ORDER!**

**LET US KNOW ABOUT YOUR ORDER EXPERIENCE AND PRODUCT SATISFACTION ON GOOGLE**



**(866) 825-8659**  
**WWW.IDEALSHIELD.COM**  
**2525 CLARK ST - DETROIT, MI 48209**



# Providing maintenance free protective products for all your facility needs

## Featured Products:

Bollard Covers, Sign Bases, Goal Posts, and Handrail



**Facility protection by Ideal Shield provides maintenance free, easy to install, heavy duty solutions for any type of facility.**

See reverse side for instructions



(866) 825-8659  
WWW.IDEALSHIELD.COM  
2525 CLARK ST - DETROIT, MI 48209